## **PRODUCT DATA SHEET**

# DUROMASTIC DURAROOF

DOUBLE CROSSLINKED COPOLYMER MEMBRANE WITH EXCELLENT CRACK-BRIDGING FOR ROOF WATERPROOFING

## DESCRIPTION

DURO MASTIC DURAROOF is a liquid crack-bridging membrane product based on a unique double crosslinked copolymer system. It does not contain plasticisers or oils that can leach, degrade or contribute to dirt-pickup. DURAROOF is used as a fully exposed membrane or a crack-bridging basecoat, or beneath a tiled mortar bed. It can withstand occasional light foot traffic. The product is water-based yet offers strong resistance to waterponding. The cured membrane combines exceptional flex and elasticity for good crack bridging properties with good tensile film strength. DURAROOF has excellent resistance to UV, colour fade and chalking. DURAROOF membrane is easily maintained, re-coated and repaired .The water content is low which enables fast drying, and thick films to be built up quickly. The product is supplied as a thixotropic liquid, which is easily applied to both vertical and horizontal surfaces. It complies fully with the test requirements of AS:4858-2004 "Wet Area Membranes" and passes at Class III, the highest level in the Australian standard.

## FEATURES

- Single component, water-based
- Exceptional elongation & crack bridging
- Excellent water resistance
- UV resistant
- High Solids
- Ease of application roller/spray/brush
- Excellent adhesion to concrete, brick, FC sheeting and render.
- Non-hazardous, low odour

## PACKAGING

• 15 Litre

## **TYPICAL PHYSICAL PROPERTIES**

**Engineered Construction Chemicals** 

Made In Australia For Over 45 Years

Colour	Pale Grey (other colours on request)
Weather Resistance	Excellent, pass +1000 hrs QUV Weatherometer, 2000 hrs UVa
Dry Time	2-4 hours @ 25°C, 50% R.H.
Recoat time	4-6 hours @ 25°C, 50% R.H.
Coverage	Total 2.0 litre/m min. Apply as 2 or more coats, each coat at 1.0 litre/m 2 As a basecoat, total 1.0 litre/m minimum as 1 to 2 coats.
Dry Film Thickness	1.2 mm minimum
Elongation	+ 550% @25°C
Tensile Strength	1.3MPa @25°C
Solids Content	60% by volume
Shelf Life	8 months in unopened containers @ 20°C
voc	9.0 g/L Green Buiding Council Compliant

## **USE AREAS**

- Exposed roofs & parapet walls
- Decks & podiums
- As a crack-bridging basecoat



#### **CONDITIONS**

It is generally accepted as good practice for "flat roofs" to be designed to clear surface water as rapidly as possible. Ensure that the roof area has adequate drainage and fall, preferably at least 1.25%, i.e. 12.5 mm fall in 1 metre. Use a sand & cement screed to ensure adequate drainage and to fill all low spots that will not drain freely. A brush or wood float finish to concrete surfaces is ideal for adhesion. If used to waterproof beneath tiled mortar beds, allow DURAROOF to dry thoroughly between coats. In winter & autumn, application in the warmest part of the day is recommended. Do not apply Hibuild WBE primer or DURAROOF below 10°C ambient . Do not apply DURAROOF above 30°C or in hot windy conditions. Excessively thick application in hot windy conditions is not advised. Do not apply during wet weather conditions, or if impending rain is likely.

#### SURFACE PREPRATION

Good surface preparation is essential for optimum performance. Concrete that has been trowel finished to a smooth surface must have all laitance removed. Remove all dust, loose particles, contaminants and curing compounds. Use sugar soap detergent and water followed by thorough rinsing to clean old concrete and other surfaces such as mineral topped bitumen. If necessary water blast unsound or powdery concrete surfaces. Fill and treat all voids, dents and nonmoving cracks. Consult Durotech for technical advice regarding moving joints and cracks. Concrete must have a minimum strength of 20 MPa and be cured a minimum of 28 days. Ensure surfaces after preparation are as dry as possible before priming.

#### **PRIMING & DETAILING**

Prime with Duromix Hibuild WBE, following the product's technical data sheet. It is essential that the application of the primer is carried out correctly. Allow the final coat of primer to dry thoroughly overnight. Next, apply DUROtech Fast Cure PU Sealant at all horizontal and vertical junctions such as floor to wall, and wall to wall. Apply a neat smooth fillet about 12mm x12mm. Remove all sealant residues and overhangs. The sealant can be coated after a good skin has formed (approx. 1 hour).

## **DUROTECH INDUSTRIES**

"This document, including any attached files, is strictly confidential and intended solely for the use of the individual or entity to which it is JAS-ANZ addressed. Durotech Industries prohibits the right to publish, copy, distribute or disclose any information contained in this document, or its attachments, by any party other than the intended recipient. If you have received this document in error please notify the sender and delete it from your system immediately. no employee or agent is authorised to conclude any binding agreement or make any representation on behalf of Durotech Industries. The views or opinions presented in this document are solely those of the author and do not necessarily represent those of Durotech Industries, except where the sender expressly, and with clear authority, states them to be the views of Durotech Industries. Durotech Industries accepts no liability for any loss or damage (direct or indirect or consequential) arising from the use of or in connection with this document and any attacchments and suggests that the recipient check this document and any attached files for the presence of viruses.

#### **APPLICATION**

Ensure that the primer is thoroughly dry and cured. Apply DURAROOF by brush/roller or airless spray in at least two or more coats to achieve a total minimum dry film thickness of 1.2 mm. Do not apply in one thick coat. Allow to dry as long as possible between coats. When dry check for pinholes and thin areas, and recoat if necessary. If membrane becomes dirty or damaged between coats, clean with water and recoat. Spills and tools should be cleaned with water before DURAROOF has dried.

#### MAINTENANCE

Then timely repair of any damage and deterioration by thorough cleaning using a little sugar soap and water, followed by thorough rinsing. When dry, apply DURAROOF.

HEALTH & SAFETY Refer Durotech MSDS prior to use.

#### **Durotech Industries Pty Ltd**

Address	14 Essex Street, P.O Box 5092, Minto,	
	NSW 2566	
Phone	+61 2 9603 1177	
Fax	+61 2 9475 5059	
Email	sales@durotechindustries.com.au	
Web	www.durotechindustries.com.au	

## Ғ 🄰 🞯 📴 in





